



HP Scanjet 7600 series document flatbed scanner Setup

HP Scanjet 7600 series 문서 평판형 스캐너 설치

English

1. Check the Box Contents

- | | |
|---|--|
| A. Scanner with automatic document feeder (ADF) | F. Warranty sheet |
| B. USB cable | G. Four or more CDs (depending on your country/region) |
| C. Power supply and power cord | H. Transparent materials adapter (TMA) for scanning slides and negatives |
| D. User's Manual (Printed or on CD 1) | I. ADF cleaning cloth |
| E. Setup Poster | |



2. Install the Software

1. Close all programs.
2. Insert CD 1 for Windows or Macintosh and follow the onscreen instructions.

Windows: If the installation does not start automatically: On Start menu, click **Run** and type: **D:\setup.exe** (where D is the letter of the CD-ROM drive).


Macintosh: Double-click the installer icon on the CD.

Note: CD 2 (Windows only) contains additional optional software. To determine which software to install, see the onscreen installation instructions.



3. Connect the Scanner and Accessories in the Order Shown

1. Connect the USB cable to the scanner and to your computer.
2. Connect the ADF cable to its port on the back of the scanner.
3. Connect the TMA cable to its port on the back of the scanner.
4. Connect the power supply and the power cord and connect it to the scanner. Plug the power cord into a surge protector or grounded wall outlet. The scanner turns on.



4. To Scan

1. Place the original face-up in the ADF or face-down on the scanner glass as indicated by the reference mark.
2. Press the appropriate button and follow the onscreen instructions.

Scanner Buttons

- Scan Document** – Scans and sends text documents to your chosen destination.
- Scan Picture** – Scans photos and graphics to the HP Image Zone software.
- File Documents** – Scans the original document in black and white to be saved on a disk or CD.
- E-Mail** – Sends the scan to your e-mail software using settings optimized for e-mail (if your software is supported).
- Copy** – Sends the scan to a printer.

For more information on how to scan see the User's Manual (printed or on CD 1) or online help. To access the User's Manual on the CD, browse CD 1, select your language directory and click on the pdf file.



Product Support

- www.hp.com/support for customer support
- www.shopping.hp.com (U.S. only) or www.hp.com (worldwide) for ordering HP accessories, supplies, and products

www.hp.com/support
www.shopping.hp.com (U.S. only)
www.hp.com (worldwide)



L1940-90110

한국어

1. 내용물 확인

- | | |
|-------------------------------|---------------------------------|
| A. 자동 문서 공급기(ADF)가 부착된 스캐너 | E. 설치 포스터 |
| B. USB 케이블 | F. 보증서 |
| C. 전원 공급 장치 및 전원 코드 | G. CD 4장 또는 이상(국가/지역에 따라) |
| D. 사용 설명서(인쇄본 또는 CD 1의 파일 사본) | H. 슬라이드 및 음화 스캔용 투명 용지 어댑터(TMA) |
| | I. ADF 청소용 천 |

2. 소프트웨어 설치

1. 모든 프로그램을 닫으십시오.
2. Windows 또는 Macintosh에서 CD 1을 넣은 후 화면의 지침을 따르십시오.

Windows: 설치가 자동으로 시작되지 않으면 다음과 같이 수행하십시오. 시작 메뉴에서 실행을 누르고 **D:\setup.exe**(D는 CD-ROM 드라이브의 문자임)를 입력하십시오.

Macintosh: CD의 설치 아이콘을 두 번 클릭하십시오.

주: CD 2(Windows만 해당)에는 추가로 선택적 소프트웨어가 포함되어 있습니다. 설치할 소프트웨어를 결정하려면, 화면의 설치 지침을 참고하십시오.

3. 스캐너와 부속품을 표시된 순서로 연결

1. 스캐너와 컴퓨터에 USB 케이블을 연결하십시오.
2. ADF 케이블을 스캐너 후면의 포트에 연결하십시오.
3. TMA 케이블을 스캐너 뒷면의 포트에 연결하십시오.
4. 전원 공급 장치와 전원 코드를 연결하고 코드를 스캐너에 연결합니다. 전원 코드를 과전류 억제기 또는 접지 콘센트에 연결합니다. 스캐너가 켜집니다.

4. 스캔

1. ADF 에 원본의 앞면이 위를 향하도록 놓거나 스캐너 유리에 앞면이 아래를 향하도록 참조 부호의 표시에 맞추어 놓으십시오.
2. 해당하는 단추를 누른 뒤 화면의 지침에 따르십시오.

스캐너 단추

- 문서 스캔** – 텍스트 문서를 스캔하여 선택한 대상으로 전송합니다.
- 그림 스캔** – 사진과 그림을 스캔하여 HP Image Zone 소프트웨어에 전송합니다.
- 파일 문서** – 원본 문서를 흑백으로 스캔해 디스크나 CD에 저장합니다.
- 전자우편** – 전자우편용으로 최적화된 설정을 사용해 스캔 내용을 전자우편 소프트웨어로 전송합니다(소프트웨어가 지원되는 경우).
- 복사** – 스캔 내용을 프린터로 전송합니다.

스캔 방법에 대한 자세한 내용은 사용 설명서(인쇄본 또는 CD 1의 파일 사본) 또는 온라인 도움말을 참조하십시오. CD의 사용 설명서를 보려면, CD 1에서 해당 언어 디렉토리를 선택하고 pdf 파일을 누릅니다.

제품 지원

- 고객 지원: www.hp.com/support
- HP 부속품, 소모품 및 제품 주문: www.shopping.hp.com(미국 전용) 또는 www.hp.com(전세계)

